



**OUTBACK
MOTORTEK**

Installation Instructions >> Rear Rack >> Africa Twin 1000

Thank you for trusting Outback Motortek with your purchase of our product. Hope you will find pride in installing and showing off the item you are just about to open. Outback Motortek products are designed and tested in Ontario, Canada and engineered and manufactured in the European Union, Hungary.

“Till the wheels fall off”

Lorry Gombos
Founder and owner
Outback Motortek



1.

Installation Instructions >> Rear Rack >> Africa Twin 1000

1. Place the four spacers on the rear end of the passenger handles.



2. Next, take the rear luggage rack and gently put it on top of the four spacer. Make sure the mounting holes all line up.



2.

COLTERRACIA MOTORCYCLE

3. Insert all four 8mmx38mm stainless steel bolts.



4. Insert the washers and thread on the nyloc nuts.



3.

COLTERRACIA MOTORCYCLE

5. Take a 5mm Allen key or Allen socket and a ratchet, also a 13mm wrench. Tighten down all four bolts.



Important: double-check all four bolts after a test ride of at least 150km or 90miles.

4.

Installation Instructions >> Rear Rack >> Africa Twin 1000

Congratulations! You've completed installing your Outback Motortek product.



Should you have any question regarding the installation, please contact us at info@outbackmotortek.com.

Or call toll free at 1 877 931 3636

Important note! Outback Motortek recommends its customer to install their products by a certified, experienced motorcycle mechanic. Outback Motortek assumes no liability for any accident, injury, death, loss, or other claim related to or resulting from the use of its products. In no event shall Outback Motortek be liable for 5. incidental or consequential damages relating to or resulting from the use of its product or any of its parts.
